



Clutch Assembly

Поз	Наименование детали		
1	Principal Axis	37	Bearing UCP205
2	Main Small Sprocket	38	Small Sprocket
3	Up Clutch Assembly	39	Top Cover
4	Main Big Sprocket	40	Spring
5	Down Clutch Assembly	41	Roller
6	Big Belt Wheel	42	Key
7	Up Bearing Pedestal	43	Bearing
8	Bearing 206	44	Clutch Cover
9	Main Oil Seal	45	Clamp Spring
10	Oil Seal Sleeve Gasket	46	Driving Pin
11	Oil Cup	47	Oil Seal
12	Dough Mixing Flange	48	Clutch Pedestal
13	Guide Wheel	49	Bearing
14	Dough Mixing Bowl		
15	Upright Pole		
16	Dough Mixing Hook		
17	Bowl Axis		
18	Bearing 206		
19	Bearing Pedestal		
20	Bearing 205		
21	Sprocket Pedestal		
22	Down Big Sprocket		
23	Chain		
24	Middle Big Sprocket		
25	Bearing		
26	Bearing Pad		
27	Medium Small Sprocket		
28	Medium Belt Wheel		
29	Small Belt Wheel		
30	Belt		
31	Adjustment Linkage		
32	Bearing		
33	Bearing		
34	Bearing Pedestal		
35	Motor		
36	Major Axis		